iRobot Roomba 551 Front Wheel Replacement

A short guide on how to effectively remove and replace the front wheel of your Roomba.

Written By: Deborah Newberry



INTRODUCTION

If you are looking to replace the side wheel, it is a slightly lengthier process that can be found here.

This is a simple guide to replace the front wheel of the Roomba, which is a simple grab and lift procedure.

Step 1 — Front Wheel




- Grab the front wheel housing on the bottom of your Roomba and lift to remove.

Step 2




- Firmly grasp the wheel, and pull to separate from the housing.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 09:42:50 AM.

